



TOP VIEW

LEGEND

- "A" PANELS
- "B" PANELS

PANEL INVENTORY

PANEL	NO. REQUIRED
A	30
B	10
TOTAL	40

ERECTION NOTES

FOLD THE FLAPS DOWNWARD BEFORE STARTING ASSEMBLY.

1. START AT TOP OF DOME.
2. 5 "A" PANELS GO TOGETHER TO CREATE THE PENTAGON AT TOP.
3. PANEL FLAPS BUTT TOGETHER. MATCH THE VELCRO PATCHES.
4. ATTACH STRAPS ACROSS PANEL JOINTS AT VERTICES.
5. AFTER PENTAGON IS ASSEMBLED WORK DOWNWARD ATTACHING NEXT ADJACENT PANELS (B'S).
6. THEN ATTACH ADJACENT "A" PANELS TO THE "B" PANELS.
7. THESE "A" PANELS WILL COME TOGETHER AT THEIR EDGES RAISING THE DOME ON THE CENTER RING.
8. THE LAST RING OF PANELS ARE ATTACHED THE SAME WAY.
9. ATTACH THE PANELS (ALL A'S) ADJACENT TO THE RING JUST COMPLETED THEN THE PANELS WHICH FILL IN THE GAPS BETWEEN THOSE JUST ATTACHED TO COMPLETE THE BASE RING.

**Dome Assembly
for EVIC 2.7.5 PMT**

amk

10.6.97